



Recommended land pattern drawing

7.16 ± 0.03
 $.282 \pm .001$
 $\varnothing \frac{4.35 \pm 0.02}{.171 \pm .001}$ (Ground pad)
 $2 \times \varnothing \frac{1.65 \pm 0.03}{.065 \pm .001}$ (Through hole)
 $\varnothing \frac{1.54 \pm 0.02}{.061 \pm .001}$
 $\varnothing \frac{0.51 \pm 0.02}{.020 \pm .001}$ (Signal pad)

